

OLYMPUS

OPERATION MANUAL

INSTRUCTIONS

OLYMPUS INTEGRATED ENDOSURGERY SYSTEM

EndoALPHA

CONTROL UNIT FOR ENDOSURGERY

UCES

Software Version 4.0

<p>This instrument manual applies ONLY to Version 4.0 of the software used with the Control Unit For Endosurgery (UCES). Also refer to the latest version's manual of software.</p> <p>USA: CAUTION : Federal law restricts this device to sale by or on the order of a physician.</p>	<p>CE</p>
--	-----------

Contents

Contents

Labels and Symbols	1
Important Information — Please Read Before Use	7
Intended use	7
Instruction manual	7
User qualifications	7
Instrument compatibility	8
Repair and modification	8
Signal words	8
Dangers, warnings and cautions	9
Chapter 1 Checking the Package Contents	12
Chapter 2 Instrument Nomenclature	15
2.1 Product list	15
2.2 Symbols and descriptions	17
2.3 EndoALPHA system diagram	28
2.4 Control unit for endosurgery (UCES)	30
2.5 Connection unit for UCES (MH-979)	33
2.6 Central operating panel for UCES (MH-980)	36
2.7 Central display for UCES (MH-981)	37
2.8 Remote controller for UCES (MH-982)	40
2.9 Optional parts	43
2.10 Switches on the central operating panel (MH-980) and their functions	44
Chapter 3 Installation and Connection	175
3.1 Installation of the UCES and MH-979	176
3.2 Connection to ancillary equipment	178
3.3 Connection to the MH-980	185
3.4 Connection to the MH-981	187
3.5 Connection to the MH-982	189
3.6 Connection to an AC mains power supply	191
3.7 Setting the DEP-3 (DEP, UP-2800P) baud rate	192
3.8 Setting the 75 Ω termination switch	193
3.9 Connection to the UCES and MH-979	194
3.10 Connection to two MH-979 units	195

Chapter 4 Inspection	196
4.1 Turn the power ON	196
4.2 MH-980 inspection	198
4.3 MH-981 inspection	201
4.4 MH-982 inspection	202
Chapter 5 Operation	203
5.1 Operating the MH-980	203
5.2 Operating the MH-982	246
5.3 Positioning the MH-981	251
5.4 After use	252
Chapter 6 Care and Storage	253
6.1 Care	253
6.2 Storage	254
6.3 Transporting the equipment on a trolley	255
Chapter 7 Troubleshooting	260
7.1 Troubleshooting guide	260
7.2 Returning EndoALPHA products for repair	280
Appendix	281
System chart	281
Operating environment	284
Specifications	284


Best Available Copy

1. Next page switch
Press to advance to Elec.Surg screen page 2.
2. Cut mode Indicator
The cut mode indicator displays the selected cut mode.
3. Coagulation mode Indicator
The coagulation mode indicator displays the selected coagulation mode.
4. Coagulation output setting Indicator
The coagulation output setting indicator displays the value set with the coagulation output control switch.
5. Coagulation output control switch
Press to set the coagulation output level.
6. Cut output setting Indicator
The cut output setting indicator displays the value set with the cut output control switch.
7. Cut output control switch
Press to set the cut output level.
8. Previous page switch
Press to return to Elec.Surg screen page 1.
9. Coagulation mode select switch
Press to select the coagulation mode (normal or spray).
10. Cut mode select switch
Press to select the cut mode (pure, blend 1 or blend 2).
11. Output mode select switch
Press to select the output mode (bipolar or monopolar).

Elec. Surg. screen (UES-20)


Elec. Surg. screen page 1

Elec. Surg. screen page 2



1. Cut output control switch
Press to set the cut output level
2. Cut output setting indicator
The cut output setting indicator displays the value set with the cut output control switch.
3. Coagulation output control switch
Press to set the coagulation output level.
4. Coagulation output setting indicator
The coagulation output setting indicator displays the value set with the coagulation output control switch.
5. Coagulation mode select switch
Press to select the coagulation mode (normal or spray).
6. Cut mode select switch
Press to select the cut mode (pure, blend 1 or blend 2).
7. Output mode select switch
Press to select the output mode (bipolar or monopolar).

- When UES-20 is connected
This screen is used to operate the UES-20.



1. Cut output control switch
Press to set the cut output level
2. Cut output setting indicator
The cut output setting indicator displays the value set with the cut output control switches.
3. Coagulation output control switch
Press to set the coagulation output level.
4. Coagulation output setting indicator
The coagulation output setting indicator displays the value set with the coagulation output control switches.
5. Coagulation mode select switch
Press to select the coagulation mode (normal or spray).
6. Cut mode select switch
Press to select the cut mode (pure, blend 1 or blend 2).
7. Output mode select switch
Press to select the output mode (bipolar or monopolar).

○ When UES-20 is selected

This screen is used to enter automatic initial setting values on the UES-20.

